



ORIGINAL

DRYWALL INSIDE AND OUTSIDE CORNER FLEX TAPE

Resists Dents,
Twice as Fast, and
Half the Compound!

Than Conventional Corner Beads & Trims

APPLICATIONS

- Inside and outside 90° corners and angled corners.
- Bay windows and coffered ceilings.

PRODUCT DESCRIPTION

- Replaces conventional corner bead. Uses half the compound.
- Slotted edges ensure superior bond and eliminates edge cracking.
- Straightens common framing irregularities for vertical corners.
- Resists dents, paint chipping, shrinkage, and common cracking problems.
- Rustproof.
- Cuts easily with a knife or scissors.
- Installs using standard compounds. No special tools or fasteners needed. No nail pops.
- Second coat of compound can be applied immediately – very light skim-coat to finish.
- Pre-finished inside corners.



PROFESSIONAL GRADE

ADVANTAGES OVER COMPETITORS

ORIGINAL	COMPETITOR PAPER/METAL TAPE	COMPETITOR METAL CORNER BEAD
Resists Cracking	Tends to Crack with Structural Movement	Tends to Crack with Structural Movement
Second Coat Immediately	Second Coat After Completely Dry	Second Coat After Completely Dry
Fastens with Compounds	Fastens with Compounds	Fastens with Screws, Nails
Superior Bonding	Good Bonding	Minimal Bonding
Will Not Rust	May Rust in Wet Areas and Humid Climates	May Rust in Wet Areas and Humid Climates

DIRECTIONS FOR USE

- 1 Measure wall height and subtract 1.3 cm (1/2"). Measure and cut ORIGINAL using a scissors or utility knife. Fold ORIGINAL in half at center crease with print side facing each other. For outside corners, fold more than the desired angle with print side facing wall. For inside corners, fold less than desired angle with print side facing out.
- 2 Most professionals prefer to cut the ends of ORIGINAL at a 45° angle.
- 3 With a 4" or 5" taping knife, apply a smooth, liberal coat of compound to corner. Press ORIGINAL into the wet compound. Adjust if necessary to create a straight line.
- 4 Wipe down tight with taping knife using a little additional pressure on the outer edges of ORIGINAL. Immediately apply a light skim coat of compound over surface of ORIGINAL. Wipe down tight and smooth. Let dry completely over several hours or overnight.
- 5 With a 6" or 8" taping knife, apply your final coat of compound feathering the compound beyond previous coat. For inside corners, a very light coat of compound is all that's needed. Let dry completely over several hours or overnight.
- 6 Sand lightly with 150 grit sandpaper. ORIGINAL will not fuzz-up like other paper or mesh tapes.

SPECIFICATIONS

- 60mm x 30.5 m roll size (2³/₈" x 100')
- Color Code BLACK
- Item#: Original-681115
UPC: 069606003648
Case Pack: 12 rolls.
24 cases per pallet
Pallet weight: 384kg (846 lb)

STORAGE

Store in a dry place protected from moisture.

Manufactured by Strait-Flex for CGC Inc.
350 Burnhamthorpe Rd. W, 5th Floor,
Mississauga, ON L5B 3J1

For product information call 1-800-387-2690 or go to cgcinc.com

